




LE1120_C400-WHT_1214-V03

		Spare part number	Spare part number	Spare part number	Colours available	
1	Sliding cover	32301	32331 <i>Mechanism Right</i>	32332 <i>Mechanism Left</i>	06	
2	Blade opener	32300			16	
3	Washer					
4	Seal parker					
5	Mechanism retainer					
6	Holding tank plate					
	Left hand version	32302			06	
	Right hand version	32328			06	
7	Seal mechanism	50724				
8	Lip seal	23721				
9	Seal plate	32304			06	
10	Screw					
11	Retainer					
12	Magnet					
13	Float arm					
14	Blade					50731
15	Bearing					
16	Blade arm					
17	Bushing					
18	Screw					
19	Blade driver					
20	Support track					
21	Screw					

		Spare part number	Spare part number	Spare part number	Colours available
22	Vent lid				
23	Vent lifter				
24	Vent Spring				
25	Vent pivot		32305		
26	Vent seal				
27	Float stem				
28	Float				
29	Vent actuator				
30	Pour out spout		32306		06
31	Measuring cup	25810			16
32	O-ring				
33	Handle cover				
34	Screw				
35	Handle				
36	Vent clip				
37	Vent button		32307		
38	Vent spring				16
39	Vent seal				
40	Waste-holding tank upper				
41	O-ring				
42	Wheel support bracket				
43	Pull handle		51805		
44	Bushing (Left/Right)				16
45	Spring				
46	Tank lock clip	51801			16
47	Wheel		32308		
48	Wheel bearing right				06
49	Wheel bearing left				
50	Waste-holding tank lower				
	Waste-holding tank complete		32327 <i>Right hand version</i>	32326 <i>Left hand version</i>	06